



02590S-A01 Scherenstromabnehmer
02590S-A01 Pantograph

04151S-039

04151S-039 Schraube
04151S-039 Screw




02154S-A01 Gehäuse kpl.
02154S-A01 Body assembly




02154S-033 Lokpfeife
02154S-034 Glocke
02154S-013 Isolatorgruppe
02154S-012 Isolator
02154S-A02 Dachsteigsatz

02154S-033 Loco whistle
02154S-034 Bell
02154S-013 Insulator group
02154S-012 Insulator
02154S-A02 Roof wire set



02154S-A03 Umschalter
02154S-003 Leuchtstab

02154S-A03 Switch assembly
02154S-003 Light transmission bar




02154S-043 Lampe CV 2
02151S-010 Schraube
02154S-A38 Kontaktplatte kpl.
04151S-031 Diode


02154S-043 Lamp CV 2
02151S-010 Screw
02154S-A38 Printed circuit assembly
04151S-031 Diode

- 02154S-026 Kupplungsfeder
- 00920S-A01 Motor
- 03237S-001 N-Kupplung
- 02151S-023 Puffer
- 02154S-A04 Getriebekasten kpl.


- 02154S-026 Coupling spring
- 00920S-A01 Motor
- 03237S-001 N-coupling
- 02151S-023 Buffer
- 02154S-A04 Gearcase assembly




- 02154S-044 Isolierplatte
- 02154S-044 Insulator plate





- 03158S-020 Schneckendeckel
- 03158S-020 Worm cover



- 03158S-015 Getriebeschnapper
- 03158S-015 Gear snap



- 02154S-021 Schnecke
- 02154S-018 Zahnrad Z=14
- 02154S-019 Zahnrad Z=12
- 02154S-020 Zahnrad Z=15/10
- 04100S-015 Zahnrad Z=14
- 03152S-015 Radkontakt




- 02154S-021 Worm
- 02154S-018 Gear T=14
- 02154S-019 Gear T=12
- 02154S-020 Gear T=15/10
- 04100S-015 Gear T=14
- 03152S-015 Wheelwiper

- 02154S-025 Getriebeboden
- 02154S-025 Gear bottom



- 02154S-A06 Haftringradsatz
- 02154S-A05 Radsatz
- 02150S-033 Haftring
- 02154S-029 Rahmen



- 02154S-A06 Traction tyre set
- 02154S-A05 Wheelset
- 02150S-033 Traction tyre
- 02154S-029 Frame

- 02154S-900 Ersatzteileblatt
- 02154S-900 Leaflet of spare parts

